

Cleaning recommendations Line Exterior

The materials of the SEFAR® Architecture Solutions line E (previous description AR) consist of 100% PTFE raw material with a coating of 100% Fluoropolymer. These materials are chemical inert.

For removing contaminations Sefar recommends the following proceeding:

General information

- Generally a lot of contaminations can be removed with hot water.
- You should always rub off stains carefully, because powerful mechanical attack can cause damage at the coating or the structure of fabric.
- Most suitable for cleaning is to use an absorbent white cloth, best of microfibers.
- Cleaning should be done from the outside to the inner side of the stain to avoid dispersing it.
- Sometimes it might be necessary to repeat the cleaning procedure for several times to remove stubborn stains. If the stains or the dirt is old and dried up it might have a negative effect on complete cleaning.

Cleaning procedure

Oil and grease

- As detergent use petroleum ether for best.
- Depending on the type of oil and grease it might be necessary to repeat the cleaning procedure for several times.

Patina

- Moisten the complete fabric with cleaning detergent "Cleanway Texdur" (by Cleanway Switzerland GmbH www.cleanway.ch, phone: 0041-32 622 50 30). Regarding the dosage please follow the information at the label of the cleaning detergent.
- The detergent should impact on the fabric for about 15 min, but not more than 30 min, to avoid damages of the coating.
- After residence time rub the cleaning agent in the fabric again, best with a soft fabric or eraser. Afterwards wash away with clear water, but do not use high pressure.

Dust and dirt

- The dust should be moistened with hot water and then rubbed off carefully.
- If the stain is still on the fabric exercise the same procedure as described under the point "Patina".

Attention!

- Cleaning detergents should always be used with care, and if necessary tested on a hidden section of the fabric.
- You should avoid using high pressure cleaners since they may damage the coating and the structure of the woven fabric. Therefore the specifications might be influenced in a negative way.
- In no case the fabric may be treated with ketones (e. g. acetone), since this damages the coating irreparably.
- Even the use of abrasive detergents or additives should be avoided because it could damage the fabric surface.

This cleaning recommendation is only a support and does not present a guarantee for the success of cleaning!

Architecture Solutions



Sefar AG
Architecture Solutions
Hinterbissastrasse 12
9410 Heiden
Switzerland

Phone +41 (0)71 898 51 04
Fax +41 (0)71 898 58 71
info@sefararchitecture.com
www.sefararchitecture.com